



**QUICK
REFERENCE GUIDE
NOVA BUS**

Version May 2010

**DRIVE STAR
Group of Companies**

★ Burlington/ON ★ Buffalo/NY ★ Dorion/QC ★

FOREWORD

To All Company Drivers and Independent Contract Drivers

We are pleased to present to you this Drive Star “Quick Reference Guide” for the operation of Nova Bus models, Version May 2010.

This booklet will allow you to quickly familiarize yourself with the idiosyncrasies of each vehicle and identify the most important controls and components you will be working with from the time of pick-up to delivery.

It is your responsibility to become familiar with the enclosed instructions.

Although you may be an experienced driver and many things within this manual are not new, you may find one item that will prevent a negligent event, incident or accident.

This is essential to all, as loss prevention is the number-one priority at the Drive Star Group of Companies.

This pocket manual was produced on behalf of your carrier by

THE ROAD-SCHOLAR™
a division of anaper trans-consult
Hamilton, Ontario
www.road-scholar.ca

The author retains all rights to its archived content in general whereas the proprietary rights to the photos, drawings, charts and schematics remain with Nova Bus.

© / issued by:

DRIVE STAR Group of Companies
1140 Waterdown Road
Burlington, Ontario L7T 4A8 Canada

www.drive-star.com

TABLE OF CONTENTS

<u>Section</u>	<u>Module</u>	<u>Subject</u>	<u>Page</u>
A		General Operating Procedures	1
		Pick-Up Inspection	1
		Pick-Up Checklist	1
		Over-the-Road Compliance	1
		Customer & Drive Star Prohibitions	2
		On-the-Road Breakdowns	2
		Electronic/Multiplex Troubleshooting Assistance	2
		Delivery of Vehicle to Consignee	2
B		Specific Instructions (applicable to all Nova Bus types)	3
		Nova Bus Models	5
		Exterior Compartments	6
		Driver Compartment	7
		Overhead Controls	7
		Miscellaneous Components	8
		Lateral Control Panel	9
		Telltale Panel	10
		Overhead Control Panel	11
		Main Engine Control Switch	12
		Battery Master Switch	13
		Pre-Trip / Daily Vehicle Inspections	14
		Rear Engine-Start &/or Parked Regeneration	16
		Fuelling Neck Plug (removed?)	16
		Fuel Gauge “yes” or “no”	17
		Tank Capacity & Fuel Consumption (40-ft)	17
		Transmission Selector	18
		Retarder Brake	18
		Specifications – 40 foot single unit	19
		Maneuverability – 40 foot single unit	20
		Swept Path / Curb-to-Curb Width	20
		Troubleshooting Tips	21
		Electronic/Multiplex Troubleshooting Assistance	25
C		62-ft “Artic” Specific Instructions	27
		Exterior Compartments	28
		Driver Compartment / Overhead Controls	29
		Lateral Control Panel	30
		Tank Capacity & Fuel Consumption	31
		Specifications	31
		Turning Radius	32

Continued....

TABLE OF CONTENTS

Continued.....62-ft “Artic” Specific Instructions		
	Maximum Pivot	32
	Swept Path / Curb-to-Curb Width	32
	Maneuverability (forward)	33
	Tight-Area Maneuvering (reverse)	33
	Fire Suppression System	34
	RECARO Driver’s Seat Controls	35
	Troubleshooting Tips	36
D	Driver Quick Reference Guide Receipt	37

END OF SECTION